

DIAMOND BELL



PORTABLE MOSQUITO REPELLER DB - 02B

IMPORTANT SAFETY INSTRUCTIONS.WARNING.

When using electric appliances, basic precautions should always be followed, including the following:
a) Read all the instructions before using the appliance. b) To reduce the risk of injury, close supervision is necessary when an appliance is used near children. c) Do not contact moving parts. d) Only use attachments recommended or sold by the manufacturer. e) Do not use outdoors.

SAVE THESE INSTRUCTIONS

Household type

Instructions for usage

1. Open the rear cover of the device and insert four 1.5V AAA batteries, preferably alkaline. Follow the steps outlined in the diagram to ensure correct placement of the batteries.

2. The LED flashes every 5-7 seconds, at which point the device begins to operate. If the indicator does not light up or you hear a beeping sound, the batteries need to be replaced.

3. Place the device in an indoor area where the mosquitos are present and no power outlets are available.


4. Avoid positioning the device in hidden areas, or obscured by curtains or furnishings. Ensure the front of the device remains unobstructed. Position the device in areas free of furniture for optimal dispersion of the ultrasound waves.

5. To keep mosquitoes away, we advise placing the device between 3 ft. (1 m) and 6 1/2 ft. (2 m) high. Avoid directing it towards open entryways or windows.

6. Recommendations:

- It is recommended to keep the device running continuously even after the mosquitos have vanished, as a preventive measure.
- If you own a pet rodent, keep it away from areas where the device is active, to avoid any issues.
- If there are mosquitos above the ceiling, in an attic or crawl space, position the device within that area.

WARNING: Do not use the device if the battery compartment is damaged or in poor condition.



Technical specifications

Coverage: 269 sq. ft. / 25 m² (open-space indoors).

Battery: 4 x 1.5 V alkaline AAA (not included).

Duration: 6 months (24h performance).

Care and maintenance

Avoid submerging the device in water or any other liquid.

Cleaning:

When cleaning the device, use only a soft, dry cloth, avoiding abrasive products.

Do not expose the device to extreme temperatures. It's advisable not to operate it in areas with temperatures exceeding 122 °F (50°C).

No refills are required:

The device operates without the need for replacement parts, making it more cost-effective.



Appropriate disposal of the device

Dispose of the device properly by placing it in the designated recycling container.

DIAMOND BELL is dedicated to environmental care and protection. The device contains electronic components and must be disposed of separately from regular household waste.


Refer to our website for relevant local regulations or contact your local health and environmental authorities for recycling options.

Terms of use and liability limitations

Improper use of this product may lead to unforeseen outcomes, and could potentially lead to violations of your country's laws.

This device is not intended for use by individuals (including children) with limited physical, sensory, or mental abilities, or those lacking experience or understanding of its operation, unless under the supervision of a responsible individual ensuring their safety. Children should be supervised to prevent them from playing with the unit.

Refer to the full terms of use and liability limitations under "Terms of Use" on thediamondbell.com



Discover more DIAMOND BELL products at: thediamondbell.com

Warranty and warranty extension

THIS WARRANTY DOES NOT AFFECT YOUR LEGAL RIGHTS



Register the device at:

www.thediamondbell.com/warranty and you will obtain a five-year warranty for the product from the date of purchase.

DIAMOND BELL does not guarantee a 100% effective barrier against the transmission of diseases that the animal may carry.

Your DIAMOND BELL device is warranted against manufacturing defects and materials for the duration prescribed by law in the country and/or state of purchase of the product (refer to www.thediamondbell.com/warranty), or for five years if registered, starting from the purchase date. If any defect arising from manufacturing or faulty materials occurs during the warranty period, DIAMOND BELL will assume responsibility for the repair or replacement of the device.

DIAMOND BELL will only be liable for repair or replacement if valid proof of purchase (e.g., paid receipt) is provided, demonstrating that the service claim date falls within the warranty period.

The warranty does not cover products or parts of products subject to normal wear and tear that naturally degrade over time.

The warranty is void if the defect results from misuse or improper maintenance of the product, or if it has been repaired or altered by unauthorized personnel by DIAMOND BELL.

To ensure optimal product performance, users must adhere strictly to the instructions provided in the user manual and refrain from any actions or uses deemed undesirable or contrary to the warnings outlined in said manual.

The warranty for certain products may be subject to limitations, such as those based on the materials utilized.

You can access any warranty restrictions applicable in each specific country or state of purchase on the website:

www.thediamondbell.com/warranty

For additional details, please review the terms and conditions of the warranty applicable in each country or state where the product is purchased, available at:

www.thediamondbell.com/warranty

Visit our website thediamondbell.com if you have any questions.

www.thediamondbell.com/certificates/db02b-ce.pdf

DIAMOND BELL Certified Warranty

PORTABLE MOSQUITO REPELLER

Serial Number (s/n)

(See the 12-digit serial number on the back of the product)

Date of purchase (MM/DD/YYYY)

__ / __ / ____